

# VX6E

No Components to remove!

Power off your VX-6

Press the 3 button`s on the right column.

2.a mode

2.b 0

2.c V/M

While holding those 3 button, press the Power button, you will heard 3 tone then with message 'ALL RESET PRESS F KEY'.

Press the F key or FW.

The VX-6 will reset all memory.

Don't do anything.. Just turn it off again.

This time, you have to press the 3 button`s on the left column. The button`s are

7.a BAND

7.b HM/RV

7.c D button or the Internet Logo

While holding those 3 button, press the Power button. You will heard the 3 tone but now you'll never see the 'ALL RESET' message.

That's it.. you're now can TX :-

040.000 - 075.995

116.750 - 124.850

135.000 - 229.995

393.500 - 492.000

OBSERVERA

Att du kanske tappar 1750 ton.

Åter ställa gör all i omvänd ordning.